

INSTALLATION INSTRUCTIONS

SY-H357NDK DUCTLESS CONVERSION KIT FOR THRU SOFFIT VENTING FOR USE WITH SY-HV-390SM POWER MODULE

1. Install SY-HV-390SM per installation instructions shipped with power module.
2. Remove aluminum filters and replace with **combination filter** furnished with kit and aluminum filter that was removed.
3. Remove backdraft damper. (Damper supplied with power module.)
4. Install the 6" round to 7" round **transition** over exhaust of unit.
5. Connect **7" round duct** to transition.
6. Cut hole in bottom of **soffit** to allow clearance for the **90° angle boot**.
7. Locate center of **4 1/4" x 10" opening** on soffit - at **horizontal centerline of hood** and **25"** above top of **liner**.
8. Layout 4 1/4" x 10" pattern and cut opening in soffit.
9. Insert 90° angle boot into soffit opening and connect boot to 7" round duct.
10. Install **grille** (included) into soffit opening.
11. Use duct tape to make all connections secure and air tight.

