



(SY-HVA-350SWTCH)

## Installation instructions for replacing push button switch in a SY-HVA-350 ventilator

**Tools required:** Phillips Screwdriver (*preferably with Magnetic Tip*)

- 1) Switch off power to unit by turning off Circuit Breaker.
- 2) Remove Liner/Ventilator Assembly from wooden range hood.
- 3) Remove Ventilator from Liner.
- 4) Remove Light Bulbs.
- 5) Remove Face Plate.
- 6) Remove 2 screws from Switch Housing Bracket located on Right side of unit.
- 7) Remove Switch from Switch Housing.
- 8) Remove 2 screws from Electrical Junction Box.
- 9) Make note of Colored Wires.
- 10) Undo Wire Harness one wire at a time and reattach corresponding colored wires from the Replacement Switch using the existing Wire Nuts.

FROM NEW SWITCH		FROM MOTOR/LIGHTS/ELECTRICAL CORD
GREY	TO	GREY FROM MOTOR
BLACK	TO	BLACK FROM MOTOR *(White on SY-HVA-500-SS unit)
RED	TO	BROWN FROM MOTOR *(Black on SY-HVA-500-SS unit)
YELLOW	TO	BLACK FROM LIGHTS
BROWN	TO	BLACK FROM ELECTRICAL CORD

- 11) Attach New Switch to Switch Housing Bracket.
- 12) Reinstall Switch Housing Bracket by fastening 2 screws to the Right side of unit.
- 13) Reinstall Electrical Junction Box Cover.
- 14) Reattach Face Plate.
- 15) Reinstall Light Bulbs.
- 16) Plug in Unit and Test.
- 17) Reinstall Liner/Ventilator assembly into wooden range hood.



\* This Switch assembly can also be used on the SY-HVA-500 unit